

Gebruiksaanwijzing

User manual

Notice d'utilisation

Benutzer-information

Koel-vriescombinatie

Fridge-Freezer

Réfrigérateurcongélateur Kühl-Gefrierschrank

Contents

Safety information	16	Care and cleaning	24
Control panel	18	What to do if	25
First use	19	Technical data	27
Daily Use	20	Installation	27
Helpful hints and tips	23	Environmental concerns	28

Subject to change without notice.



Safety information

In the interest of your safety and to ensure the correct use, before installing and first using the appliance, read this user manual carefully, including its hints and warnings. To avoid unnecessary mistakes and accidents, it is important to ensure that all people using the appliance are thoroughly familiar with its operation and safety features. Save these instructions and make sure that they remain with the appliance if it is moved or sold, so that everyone using it through its life will be properly informed on appliance use and safety.

For the safety of life and property keep the precautions of these user's instructions as the manufacturer is not responsible for damages caused by omission.

Children and vulnerable people safety

 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

- Keep all packaging well away from children. There is risk of suffocation.
- If you are discarding the appliance pull
 the plug out of the socket, cut the connection cable (as close to the appliance
 as you can) and remove the door to prevent playing children to suffer electric
 shock or to close themselves into it.
- If this appliance featuring magnetic door seals is to replace an older appliance having a spring lock (latch) on the door or lid, be sure to make that spring lock unusable before you discard the old appli-

ance. This will prevent it from becoming a death trap for a child.

General safety



Warning!

Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

- The appliance is intended for keeping foodstuff and/or beverages in a normal household as explained in this instruction booklet.
- Do not use a mechanical device or any artificial means to speed up the thawing process.
- Do not use other electrical appliances (such as ice cream makers) inside of refrigerating appliances, unless they are approved for this purpose by the manufacturer.
- Do not damage the refrigerant circuit.
- The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable.

During transportation and installation of the appliance, be certain that none of the components of the refrigerant circuit become damaged.

If the refrigerant circuit should become damaged:

- avoid open flames and sources of ignition
- thoroughly ventilate the room in which the appliance is situated
- It is dangerous to alter the specifications or modify this product in any way. Any damage to the cord may cause a shortcircuit, fire and/or electric shock.

- / Warning! Any electrical component (power cord, plug, compressor) must be replaced by a certified service agent or qualified service personnel to avoid hazard.
 - Power cord must not be lengthened.
 - 2. Make sure that the power plug is not squashed or damaged by the back of the appliance. A squashed or damaged power plug may overheat and cause a fire.
 - Make sure that you can come to the mains plug of the appliance.
 - 4. Do not pull the mains cable.
 - 5. If the power plug socket is loose, do not insert the power plug. There is a risk of electric shock or fire.
 - 6. You must not operate the appliance without the lamp cover (if foreseen) of interior lightina.
- This appliance is heavy. Care should be taken when moving it.
- Do not remove nor touch items from the freezer compartment if your hands are damp/wet, as this could cause skin abrasions or frost/freezer burns.
- Avoid prolonged exposure of the appliance to direct sunlight.
- Bulb lamps (if foreseen) used in this appliance are special purpose lamps selected for household appliances use only. They are not suitable for household room illumination.

Daily Use

- Do not put hot pot on the plastic parts in the appliance.
- Do not store flammable gas and liquid in the appliance, because they may explode.
- Do not place food products directly against the air outlet on the rear wall. (If the appliance is Frost Free)
- Frozen food must not be re-frozen once it has been thawed out.
- Store pre-packed frozen food in accordance with the frozen food manufacturer's instructions.
- Appliance's manufacturers storage recommendations should be strictly adhered to. Refer to relevant instructions.

- Do not place carbonated or fizzy drinks in the freezer compartment as it creates pressure on the container, which may cause it to explode, resulting in damage to the appliance.
- Ice Iollies can cause frost burns if consumed straight from the appliance.

Care and cleaning

- Before maintenance, switch off the appliance and disconnect the mains plug from the mains socket.
- Do not clean the appliance with metal objects.
- Do not use sharp objects to remove frost from the appliance. Use a plastic scraper.
- Regularly examine the drain in the refrigerator for defrosted water. If necessary, clean the drain. If the drain is blocked. water will collect in the bottom of the appliance.

Installation

Important! For electrical connection carefully follow the instructions given in specific paragraphs.

- Unpack the appliance and check if there are damages on it. Do not connect the appliance if it is damaged. Report possible damages immediately to the place you bought it. In that case retain packing.
- It is advisable to wait at least four hours before connecting the appliance to allow the oil to flow back in the compressor.
- Adequate air circulation should be around the appliance, lacking this leads to overheating. To achieve sufficient ventilation follow the instructions relevant to installation.
- Wherever possible the back of the product should be against a wall to avoid touching or catching warm parts (compressor, condenser) to prevent possible burn.
- The appliance must not be located close to radiators or cookers.
- Make sure that the mains plug is accessible after the installation of the appliance.
- Connect to potable water supply only (If a water connection is foreseen).

Service

- Any electrical work required to do the servicing of the appliance should be carried out by a qualified electrician or competent person.
- This product must be serviced by an authorized Service Centre, and only genuine spare parts must be used.


Environment Protection

This appliance does not contain gasses which could damage the ozone layer,

in either its refrigerant circuit or insulation materials. The appliance shall not be discarded together with the urban refuse and rubbish. The insulation foam contains flammable gases: the appliance shall be disposed according to the applicable regulations to obtain from your local authorities. Avoid damaging the cooling unit, especially at the rear near the heat exchanger. The materials used on this appliance marked by the symbol \triangle are recyclable.

Control panel

Fridge Control panel



- 1. Pilot liaht
- 2. ON/OFF switch
- 3. Temperature regulator (warmest)
- 4. Temperature indicator
- 5. Temperature regulator (coldest)
- 6. Supercool light
- Supercool switch

Switching on

Insert the plug into the wall socket. Press the ON/OFF switch. The Pilot Light will light up.

Switching off

The fridge is shut off by pressing the ON/ OFF switch until the Pilot light and the Temperature indicator switched off.

Temperature regulation

The temperature can be adjusted between +3°C and +8°C.

By pressing the Temperature regulators, the current temperature setting flashes on the Temperature indicator. It is possible to modify the setting temperature only with flashing indicator. To set a warmer temperature, press warmest Temperature regulator. To set a colder temperature, press coldest Temperature regulator. The Temperature indicator displays the newly selected temperature.

The newly selected-temperature will be reached within 24 hours.

Temperature indicator

During normal functioning the Temperature indicator shows the temperature currently set.

Supercool function

The Supercool function is suited for quick cooling of large quantities of goods in the refrigerator.

To activate the function, do these steps:


- 1. Press the Supercool button.
- The Supercool indicator switches on. The Supercool function now provides for intensive coolina.

The Supercool function is ended automatically after a period of 6 hours.

You can deactivate the function at any time:

- Press the Supercool button.
- 2. The Supercool indicator switches off.

Freezer Control panel



- 1. Pilot liaht
- 2. ON/OFF switch
- 3. Temperature regulator (warmest)
- 4. Temperature indicator
- 5. Temperature regulator (coldest)
- 6. Fast Freezing light
- 7. Fast Freezing switch
- 8. Alarm light
- 9. Alarm reset switch

Switching on

Insert the plug into the wall socket. Press the ON/OFF switch .
The Pilot Light will light up.

Switching off

The freezer is shut off by pressing the ON/ OFF switch until the Pilot light and the Temperature indicator switched off.

Temperature regulation

The temperature can be adjusted between -15°C and -24°C.

By pressing the Temperature regulators, the current temperature setting flashes on the Temperature indicator. It is possible to modify the setting temperature only with flashing indicator. To set a warmer temperature, press warmest Temperature regulator. To set a colder temperature, press coldest Temperature regulator. The Temperature indicator displays the newly selected temperature.

The newly selected-temperature will be reached within 24 hours.

Temperature indicator

During normal functioning the Temperature indicator shows the latest set temperature.

Fast freezing function

Press the Fast freezing switch to activate the Fast freezing function.

The Fast freezing light will light up. This function stops automatically after 52 hours.

Press the Fast freezing switch to deactivate the function at any time.

The Fast freezing light will switch off.

Excessive temperature alarm

In the event of an abnormal temperature rise inside the freezer (e.g. power cut) Alarm light will start to flash and a buzzer will sound.

After the temperature has returned to normal, the Alarm light will continue to flash, although the buzzer has stopped.

When the Alarm reset switch is pressed, the warmest temperature reached in the compartment flashes on the Temperature indicator.

If the power has been off for a long time, frozen food should be consumed as quickly as possible, or cooked and then re-frozen.

First use

Cleaning the interior

Before using the appliance for the first time, wash the interior and all internal accessories with lukewarm water and some neutral soap so as to remove the typical smell of a brand-new product, then dry thoroughly.

Important! Do not use detergents or abrasive powders, as these will damage the finish.

Daily Use

Freezing fresh food

The freezer compartment is suitable for freezing fresh food and storing frozen and deep-frozen food for a long time.

To freeze fresh food activate the Fast Freezing function at least 24 hours before placing the food to be frozen in the freezer compartment.

Place the fresh food to be frozen in the top compartment.

The maximum amount of food that can be frozen in 24 hours is specified on the rating plate, a label located on the inside of the fridge.

The freezing process lasts 24 hours: during this period do not add other food to be frozen.

After 24 hours, when the freezing process is completed, deactivate the Fast Freezing function (see "Fast Freezing function").

Important! When use the Fast Freezing function:

about 6 hours be- fore	Introducing small quantities of fresh food (about 5 kg)
about 24 hours be- fore	Introducing the maximum quantity of food (see rating plate)
not needed	Introducing frozen food
not needed	Introducing small quantities of fresh food daily 2 kg maximum

Storage of frozen food

When first starting-up or after a period out of use, before putting the products in the compartment let the appliance run at least 2 hours on the higher settings.

Important! In the event of accidental defrosting, for example due to a power failure, if the power has been off for longer than the value shown in the technical characteristics chart under "rising time", the defrosted food must be consumed quickly or cooked immediately and then re-frozen (after cooling).

Ice-cube production

This appliance is equipped with one or more trays for the production of ice-cubes.

Fill these trays with water, then put them in the freezer compartment.

Important! Do not use metallic instruments to remove the travs from the freezer.

Thawing


Deep-frozen or frozen food, prior to being used, can be thawed in the refrigerator compartment or at room temperature, depending on the time available for this operation.

Small pieces may even be cooked still frozen, directly from the freezer: in this case, cooking will take longer.

Movable shelves

The walls of the refrigerator are equipped with a series of runners so that the shelves can be positioned as desired.

For better use of space, the front halfshelves can lie over the rear ones.




Positioning the door shelves

To permit storage of food packages of various sizes, the door shelves can be placed at different heights.

To make these adjustments proceed as follows:

gradually pull the shelf in the direction of the arrows until it comes free, then reposition as required.



0°C Compartment

In the 0°C compartment the temperature is controlled automatically. It stays constantly at about 0°C, no adjustment is necessary. The constant storage temperature of about 0°C and the relative humidity of between 45 and 90 % provide optimal conditions for the various kinds of food.

Important!

You can therefore store a variety of fresh food in the 0°C compartment, where it will last up to 3 times longer with better quality compared to normal refrigerator compartments. This allows you to stock more fresh food. Taste, degree of freshness, quality and nutritional values (vitamins and minerals) are well preserved. Loss of weight in

vegetables and fruit diminishes. Food yields a higher degree of nutritional value.

Important!

The 0°C compartment is also suitable for defrosting food.


In this case the thawed food can be stored up to two days.

Humidity control

Both drawers can be used according to the desired storage conditions independently of each other with lower or higher humidity. Regulation for each drawer is separate and is controlled using the slide valve at the front of the drawer.

- "Dry": low air humidity up to 50 % relative humidity
 - This humidity level is reached when both sliders are set into this position ∆ and the ventilation openings are wide open.
- Humid": high relative humidity up to 90%

This humidity level is reached when both sliders are set in this position \(\)\(\\ \\ \\ \) and the ventilation openings are closed. Humidity is kept and can not escape.



Storage time in the 0°C compartment for fresh food

Type of food	Air humidity adjustment	Storage time
Onion	ð "dry"	up to 5 months
Butter	ð "dry"	up to 1 month
Large pork cuts	ð "dry"	up to 10 days
Beef, venison, small pork cuts, poultry	∆ "dry"	up to 7 days
Tomato sauce	ð "dry"	up to 4 days
Fish, shellfish, cooked meat products	∆ "dry"	up to 3 days
Cooked seafood	ð "dry"	up to 2 days

Type of food	Air humidity adjustment	Storage time
Salad, vegetables Carrots, herbs, Brussels sprouts, celery	♦ "humid"	up to 1 month
Artichokes, cauliflower, chicory, iceberg lettuce, endive, lamb's lettuce, lettuce, leeks, radicchio	♦ "humid"	up to 21 days
Broccoli, Chinese leaves, kale, cabbage, radishes, Savoy cabbage	♦ "humid"	up to 14 days
Peas, kohlrabi	♦ % "humid"	up to 10 days
Spring onions, radishes, asparagus, spinach	♦ "humid"	up to 7 days
Fruit 1) Pears, dates (fresh), strawberries, peaches 1)	♦ "humid"	up to 1 month
Plums ¹⁾ rhubarb, gooseberries	♦ "humid"	up to 21 days
Apples (not sensitive to cold), quinces	♦ % "humid"	up to 20 days
Apricots, cherries	♦ % "humid"	up to 14 days
Damsons, grapes	♦ % "humid"	up to 10 days
Blackberries, currants	♦ % "humid"	up to 8 days
Figs (fresh)	♦ % "humid"	up to 7 days
Blueberries, raspberries	♦ "humid"	up to 5 days

¹⁾ The riper the fruit, the shorter the storage time

Important!

Cakes containing cream and other kinds of pastry products can be stored in the 0°C compartment for 2 or 3 days.

Important!

Not to be placed in the 0°C compartment:

- cold sensitive fruit which have to be stored at cellar or room temperature like pineapple, bananas, grapefruit, melons, mango, papaya, oranges, lemons, kiwi fruit.
- The types of food not mentioned above should be stored in the refrigerator compartment (e.g. all sorts of cheese, cold cuts, etc.)

Important!

The level of air humidity in the drawers depends on the content of humidity in the stored food, vegetable and fruit and on the frequency of door opening

The 0°C compartment is also suitable for slow thawing of food. In this case the thawed food can be stored in the 0°C compartment for up to two days.

Tips:

- Pay attention to the freshness of the food, especially on the expiry date. Quality and freshness influence the storage time.
- The whole storage cycle time will depend on the preservation conditions made prior to the final storage in the fridge.
- Food, fruit or vegetables should always be packed or wrapped up before storage.
- Animal food always store packed and dry.
- Food rich in proteins will go bad quicker. This means seafood will spoil before fish which in turn will spoil before meat. While storing food in a 0°C compartment storage time for that kind of food can be in-


- creased by up to three times as well without loss on quality.
- All food stored in a 0°C compartment should be taken out of the drawers roughly 15-30 min before consumption, particularly fruit and vegetables to be consumed without any additional cooking process. Allowing fruit and vegetables to return to room temperature will improve the texture and flavour.

Drawer

The wire shelves inside the drawers permit that air can circulate freely and consequently a better conservation of foods.

The compartment has stops to prevent the drawers from falling out when fully extended.

To remove the drawers (e.g. for cleaning purposes), pull them out as far as the stops, lift and extract.



Helpful hints and tips

Hints for energy saving

- Do not open the door frequently or leave it open longer than absolutely necessary.
- If the ambient temperature is high and the Temperature Regulator is set to low temperature and the appliance is fully loaded, the compressor may run continuously, causing frost or ice on the evaporator. If this happens, set the Temperature Regulator toward warmer settings to allow automatic defrosting and so a saving in electricity consumption.

Hints for fresh food refrigeration

To obtain the best performance:

- do not store warm food or evaporating liquids in the refrigerator
- do cover or wrap the food, particularly if it has a strong flavour
- position food so that air can circulate freely around it

Hints for refrigeration

Useful hints:

Meat (all types): wrap in polythene bags and place on the glass shelf above the vegetable drawer.

For safety, store in this way only one or two days at the most.

Cooked foods, cold dishes, etc... these should be covered and may be placed on any shelf.

Fruit and vegetables: these should be thoroughly cleaned and placed in the special drawer(s) provided.

Butter and cheese: these should be placed in special airtight containers or wrapped in aluminium foil or polythene bags to exclude as much air as possible.

Milk bottles: these should have a cap and should be stored in the bottle rack on the door.

Bananas, potatoes, onions and garlic, if not packed, must not be kept in the refrigerator.

Hints for freezing

To help you make the most of the freezing process, here are some important hints:

- the maximum quantity of food which can be frozen in 24 hrs. is shown on the rating plate;
- the freezing process takes 24 hours. No further food to be frozen should be added during this period;
- only freeze top quality, fresh and thoroughly cleaned, foodstuffs;
- prepare food in small portions to enable it to be rapidly and completely frozen and

- to make it possible subsequently to thaw only the quantity required:
- wrap up the food in aluminium foil or polythene and make sure that the packages are airtight:
- do not allow fresh, unfrozen food to touch food which is already frozen, thus avoiding a rise in temperature of the lat-
- lean foods store better and longer than fatty ones: salt reduces the storage life of
- water ices, if consumed immediately after removal from the freezer compartment. can possibly cause the skin to be freeze burnt:
- it is advisable to show the freezing in date on each individual pack to enable you to keep tab of the storage time.

Hints for storage of frozen food

To obtain the best performance from this appliance, you should:

- make sure that the commercially frozen foodstuffs were adequately stored by the retailer:
- be sure that frozen foodstuffs are transferred from the foodstore to the freezer in the shortest possible time;
- not open the door frequently or leave it open longer than absolutely necessary;
- once defrosted, food deteriorates rapidly and cannot be refrozen:
- do not exceed the storage period indicated by the food manufacturer.

Care and cleaning



Caution! Unplug the appliance before carrying out any maintenance operation.



This appliance contains hydrocarbons in its cooling unit; maintenance and recharging must therefore only be carried out by authorized technicians.

Periodic cleaning

The equipment has to be cleaned regularly:

- · clean the inside and accessories with lukewarm water and some neutral soap.
- regularly check the door seals and wipe clean to ensure they are clean and free from debris.
- rinse and dry thoroughly.

Important! Do not pull, move or damage any pipes and/or cables inside the cabinet. Never use detergents, abrasive powders, highly perfumed cleaning products or wax polishes to clean the interior as this will damage the surface and leave a strong odor.

Clean the condenser (black grill) and the compressor at the back of the appliance with a brush. This operation will improve the performance of the appliance and save electricity consumption.

The lowest shelf, dividing the cooler compartment from the 0°C compartment can

be removed only for cleaning. To remove pull out the shelf straight.

The cover plates above the drawers in the compartment can be taken out for cleaning.

Important!

To make sure fully functionality of the 0°C compartment the lowest shelf and cover plates must be put back in their original position after cleaning.

Important! Take care of not to damage the cooling system.

Many proprietary kitchen surface cleaners contain chemicals that can attack/damage the plastics used in this appliance. For this reason it is recommended that the outer casing of this appliance is only cleaned with warm water with a little washing-up liquid added.

After cleaning, reconnect the equipment to the mains supply.

Defrosting of the refrigerator

Defrosting of the fridge compartment is automatic.

The water that forms flows into a recipient on the compressor and evaporates. This recipient cannot be removed.


Defrosting the freezer

A certain amount of frost will always form on the freezer shelves and around the top compartment.

Defrost the freezer when the frost layer reaches a thickness of about 3-5 mm.

To remove the frost, follow the instructions. below:

- pull out the plug from the wall socket or switch off the appliance
- remove any stored food, wrap it in several layers of newspaper and put it in a cool place
- leave the door open and insert the plastic scraper in the appropriate seating at the bottom centre, placing a basin underneath to collect the defrost water



 when defrosting is completed, dry the interior thoroughly and keep the scraper for future use

- turn the thermostat knob back to the required setting or replace the plug in the power socket
- after two or three hours, reload the previously removed food into the compart-

It is recommended to operate the appliance at the highest position of the thermostatic control for some hours so that it can reach the sufficient storing temperature as soon as possible.

Important! Never use sharp metal tools to scrape off frost from the evaporator as you could damage it. Do not use a mechanical device or any artificial means to speed up the thawing process other than those recommended by the manufacturer. A temperature rise of the frozen food packs. during defrosting, may shorten their safe storage life.

Periods of non-operation

When the appliance is not in use for long periods, take the following precautions:

- disconnect the appliance from electricity supply
- remove all food
- defrost (if foreseen) and clean the appliance and all accessories
- leave the door/doors ajar to prevent unpleasant smells.

If the cabinet will be kept on, ask somebody to check it once in a while to prevent the food inside from spoiling in case of a power failure.

What to do if...



Warning! Before troubleshooting, disconnect the mains plug from the mains socket.

Only a qualified electrician or competent person must do the troubleshooting that is not in this manual.

Important! There are some sounds during normal use (compressor, refrigerant circulation).


Problem	Possible cause	Solution
The appliance does not operate. The lamp does not operate.	The appliance is switched off.	Switch on the appliance.
	The mains plug is not connected to the mains socket correctly.	Connect the mains plug to the mains socket correctly.

Problem	Possible cause	Solution
	The appliance has no power. There is no voltage in the mains socket.	Connect a different electrical appliance to the mains socket. Contact a qualified electrician.
The buzzer sounds.	The temperature in the freezer is too high.	Refer to "Excessive Temperature Alarm"
The lamp does not work.	The lamp is in stand-by.	Close and open the door.
	The lamp is defective.	Refer to "Replacing the lamp".
The compressor operates continually.	The temperature is not set correctly.	Set a higher temperature.
	The door is not closed correctly.	Refer to "Closing the door".
	The door has been opened too frequently.	Do not keep the door open longer than necessary.
	The product temperature is too high.	Let the product temperature decrease to room temperature before storage.
	The room temperature is too high.	Decrease the room temperature.
Water flows on the rear plate of the refrigerator.	During the automatic defrosting process, frost defrosts on the rear plate.	This is correct.
Water flows on the ground.	The melting water outlet does not flow in the evaporative tray above the compressor.	Attach the melting water outlet to the evaporative tray.
The temperature in the appliance is too low.	The temperature regulator is not set correctly.	Set a higher temperature.
The temperature in the appliance is too high.	The temperature regulator is not set correctly.	Set a lower temperature.
	The door is not closed correctly.	Refer to "Closing the door".
	The product temperature is too high.	Let the product temperature decrease to room temperature before storage.
	Many products are stored at the same time.	Store less products at the same time.
The temperature in the refrigerator is too high.	There is no cold air circulation in the appliance.	Make sure that there is cold air circulation in the appliance.
The temperature in the freezer is too high.	Products are too near to each other.	Store products so that there is cold air circulation.

Replacing the bulb

If you want to replace the bulb, do these steps:

- 1. Break the circuit of the appliance.
- Press on the rear hook and at the same time slide the cover in the direction of the arrow.
- Replace the bulb with one of the same power and specifically designed for household appliances. (the maximum power is shown on the light bulb cover)
- 4. Replace the light cover by sliding it into its original position.
- 5. Reconnect the appliance.
- 6. Open the door and check if the light comes on.



Closing the door

- 1. Clean the door gaskets.
- If necessary, adjust the door. Refer to "Installation".
- 3. If necessary, replace the defective door gaskets. Contact the Service Center.

Technical data

Dimension of the recess		
	Height	1780 mm
	Width	560 mm
	Depth	550 mm
Rising Time		18 h
Voltage		230-240 V
Frequency		50 Hz

The technical information are situated in the rating plate on the internal left side of the appliance and in the energy label.

Installation



Read the "Safety Information" carefully for your safety and correct operation of the appliance before installing the appliance.

Positioning

Install this appliance at a location where the ambient temperature corresponds to the climate class indicated on the rating plate of the appliance:

Climate class	Ambient temperature
SN	+10°C to + 32°C
N	+16°C to + 32°C
ST	+16°C to + 38°C
Т	+16°C to + 43°C

Electrical connection


Before plugging in, ensure that the voltage and frequency shown on the rating plate correspond to your domestic power supply. The appliance must be earthed. The power supply cable plug is provided with a contact for this purpose. If the domestic power supply socket is not earthed, connect the appliance to a separate earth in compliance with current regulations, consulting a qualified electrician.

The manufacturer declines all responsibility if the above safety precautions are not observed.

This appliance complies with the E.E.C. Directives.

Ventilation requirements

The airflow behind the appliance must be sufficient.



Environmental concerns

The symbol and on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative

consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council, your household waste disposal service or the shop where you purchased the product.