


# Anschlußplan

**MWGD 750.0E**  
8541 963 01711



Up = Upper contact of primary winding HT-transformer  
Lo = Lower contact of primary winding HT-transformer


COLOUR CODE	FARBKODE	CODE DE COULEUR
YW	YELLOW	GELB JAUNE
WT	WHITE	WEISS BLANC
RD	RED	ROT ROUGE
GY	GREY	GRAU GRIS
BR	BROWN	BRAUN BRUN
BLK	BLACK	SCHWARZ NOIR
BL	BLUE	BLAU BLEU
Y/G	YELLOW-GREEN	GELB-GRÜN JAUNE-VERT

1040=Secondary door switch      Oven in off position  
with door closed  
1050=Monitor door switch      Herd abgeschaltet  
Tur geschlossen  
1060=Primary door switch      Four debranche  
porte ferme

8538-965-01791

# Stromlaufplan

MWGD 750.0E  
8541 963 01711





\*Only present in Grill/Crisp versions

# Stromlaufplan

## MWGD 750.0E


8541 963 01711



4619 688 04701

# Stromlaufplan MWGD 750.0E

8541 963 01711



4619 688 04721