

Responsible: D. Rutz  
Date: 17.02.2010

Tel.: (0209) 401 733  
Fax: (0209) 401 743



---

## Error messages

**Models affected: EMWG 9500.0 - EMWK 9500.0**

Some errors are shown as an error code in the display: The following is a list of possible error displays:

<i><b>Error code</b></i>	<i><b>Error description</b></i>
ERR 1	Microwave relay error
ERR 2	Keyboard / user interface error
ERR 3	Oven sensor error
ERR 4	Internal temperature sensor error
ERR 7	Humidity sensor error
ERR 8	EEPROM writing error
ERR 9	EEPROM empty / not described EEPROM total error