

Responsible: Dieter Rutz  
Date: 17.06.2013

Tel.: (0209) 401 733  
Fax: (0209) 401 743




---


## **EEBP 6260.0**

### **Oven door remains locked after the pyrolysis program has been completed**

The pyrolysis program has been completed but the oven door is locked (2 hours). The cross flow fan may still be operating.

The oven door remains locked and the symbol  blinks.

Please proceed as follows:

1. Set the function selection button at 0 and wait 1 minute
2. Turn the function selection button into position  and wait for 2 minutes.
3. Return the function selection button to 0 and wait until the lamp goes off (approx. 5 minutes). You will then be able to open the oven door.