Responsible: N. Kirchmair Tel.: (0209) 401 718 Date: 29.10.2008 Fax: (0209) 401 743



EEB 6800.5 Moisture behind the glass panel Problems with operating the electronic unit due to moisture

Two-step remedy

Step 1 - Sealing

- 1. Remove the appliance.
- 2. Disconnect the appliance from the mains.
- 3. Screw off the two screws of the cover behind the control panel and remove the cover.
- Screw off the four screws of the back wall of the appliance and remove it.
- 5. Screw off the four screws of the cover with the cross-flow fan duct and remove the cover.
- Turn the bottom of the cover upwards and apply the sealant (spare-part no. 535565) to the front edge across the full width of the appliance.
- 20/10/2004 (10/15)



- 7. Re-mount the cover with the cross-flow fan duct. The seal is now located between the control panel support and the cover.
- 8. Replace the cover behind the control panel.
- 9. Carry out a VDE 0701 test and reinstall the appliance.

Step 2 - Sealing

- 1. Remove the oven door.
- Seal the gap between the glass switch panel and the control panel holder from beneath across the full width of the panel with Pactan (spare-part no. 091580).



